

FITTING INSTRUCTIONS TO BE FITTED BY A QUALIFIED TECHNICIAN GBRacing® World Class Motorcycle Protection

#### THIS SHEET INCLUDES FITTING INSTRUCTIONS FOR THE FOLLOWING PARTS:

Secondary Alternator Cover Part No. EC-F3-675-1-GBR / Secondary Clutch Cover Part No. EC-F3-675-2-GBR



# SECONDARY ALTERNATOR COVER PART NO. EC-F3-675-1-GBR


- 1 Remove 5 fairing bolts as shown in picture to maneuver fairing away for access to Bolt 3 and use cloth to protect fairing.
- 2 Remove 4 existing bolts from the stock Alternator cover, shown as position Bolt 1, 2, 3 & 4.
- 3 Place the Secondary Alternator Cover over the stock cover.
- 4 Assemble 4 replacement bolts loosely in the correct position as shown.
- 5 Tighten bolts to a Torque of 8 Nm as per manufacturer's recommendations. DO NOT OVERTIGHTEN.
- 6 Re-fit 5 fairing bolts
- 7 Re-Fit lower Fairing.



Remove 5 Fairing Bolts



**GBRacing Bolt 3** 



## SECONDARY CLUTCH COVER PART NO. EC-F3-675-2-GBR

- 1 Remove 4 existing bolts from the stock Clutch cover, shown as position Bolt 1, 2, 3 & 4.
- 2 Place the Secondary Clutch Cover over the stock cover.
- 3 Assemble 4 replacement bolts loosely in the correct position as shown.
- 4 Tighten bolts to a Torque of 8 Nm as per manufacturer's recommendations. DO NOT OVERTIGHTEN.





Bolt 2

#### Engine Cover Set: EC-F3-675-SET-GBR

EC-F3-675-1-GBR, EC-F3-675-2-GBR

### www.GBRacing.eu