



THIS SHEET INCLUDES FITTING INSTRUCTIONS FOR THE FOLLOWING PARTS:

Secondary Alternator Cover Part No. EC-V4-2018-1-GBR / Secondary Clutch Cover Part No. EC-V4-2018-2-GBR



SECONDARY ALTERNATOR COVER PART NO. EC-V4-2018-1-GBR

1. Remove the left hand side fairing panel.
2. Remove the 4 standard bolts as shown in Fig 1.
3. Place the secondary alternator cover against the standard alternator.
4. Insert the 4 supplied bolts and tighten to 11Nm as per Manufacturer's recommendations. DO NOT OVERTIGHTEN
5. Replace the left hand side fairing panel.


Bolt 1
M6X30A2-TORX - 11Nm

Bolt 2
M6X30A2-TORX - 11Nm



Bolt 4
M6X30A2-TORX - 11Nm

Bolt 3
M6X30A2-TORX - 11Nm



SECONDARY CLUTCH COVER PART NO. EC-V4-2018-2-GBR

1. Remove right hand side fairing panel.
2. Remove 4 existing bolts from the Clutch cover, shown as position Bolt 1, 2, 3 & 4.
3. Place the Secondary Clutch Cover over the stock cover.
4. Assemble 4 replacement bolts loosely in the correct position as shown.
5. Tighten bolts to a Torque of 11Nm as per manufacturer's recommendations. DO NOT OVERTIGHTEN.
6. Replace right hand side fairing panel.


Bolt 2
M6X30A2-TORX - 11Nm

Bolt 3
M6X30A2-TORX - 11Nm



Bolt 1
M6X30A2-TORX - 11Nm

Bolt 4
M6X30A2-TORX - 11Nm



ENGINE COVER SET: Part No. EC-V4-2018-SET-GBR

EC-V4-2018-1-GBR, EC-V4-2018-2-GBR

www.GBRacing.de